

3M™ Thermally Conductive Interface Tapes TM-671SA and TM-672SA

Product Description

3M™ Thermally Conductive Interface Tapes TM-671SA and TM-672SA are pressure sensitive adhesive tapes filled with thermally conductive ceramic particles with thicknesses of 0.375 and 0.5mm.

Features and Benefits

- High/low adhesion construction (face side or non-liner size is lower adhesion) for good reworkability
- Halogen free*
- Good thermal conductivity (>0.5 W/m-K)
- Fine electrical insulation
- Low thermal impedance
- Vibration damping
- Good and reliable adhesion performance against Al and SUS

Product Uses

This product can be used for heat management of electronic devices for general heat dissipation devices and other bonding/joining parts in electronic products.

Construction

3M™ Thermally Conductive Interface Tapes		
	TM-671SA	TM-672SA
Adhesive Type	Soft Acrylic Adhesive	
Tape Thickness (mm)	0.375	0.50 (±0.5mm)
Tape Color	White (slightly grey dotted)	
Filler Type	Ceramic Particle	
Product Liner	130 µm Paper Liner with red 3M Logo	
Roll Length	Standard: 33MT Custom size can be supplied by request.	

*Halogen Free is defined as having maximum 900 ppm bromine, maximum 900 ppm chlorine, and/or maximum 1500 ppm total bromine and chlorine, per IEC 61249-2-21.



Applications

- Battery Thermal Management
- Heatsink-Thermal Interface Attachment
- Heatsink-Thermal Interface Material
- LED Lighting Thermal Management
- Thermal Interface-Damping-Cushioning

Mechanical fastening such as clamp, bracket, screw can be used in parallel with 3M™ Thermally Conductive Interface Tapes TM-671SA and TM-672SA.

Typical Physical Properties and Performance Characteristics

Note: The following technical information and data should be considered representative or typical only and should not be used for specification purposes.

			3M™ Thermally Conductive Interface Tapes	
			TM-671SA	TM-672SA
			Unit: grams/12.7mm width	
ASTM D-330 90° Peel Adhesion Crosshead speed: 508mm/min. 72 hr dwell at 70°C SUS 304 test substrate	Liner side Non-liner side		>3800 >1200	>4000 >1500
ASTM D-1002 Dynamic Shear Crosshead speed: 305mm/min.	Initial Strength (SUS to SUS)		>35	>30
Foam Density (grams/cm³)			1.4 (±0.09)	
Thermal Conductivity (W/m-K on plane direction)			0.60	

Application Notes

- Bond strength is dependent upon the amount of adhesive to surface contact developed. Firm application pressure helps to develop better adhesive contact and improve bonding strength.
- To obtain optimum adhesion, the bonding surfaces must be clean, dry and well unified. Typical surface cleaning solvents are isopropyl alcohol and water (rubbing alcohol) or heptane. **Note:** Be sure to follow the manufacturer's safety precautions and directions for use when using solvents.
- Ideal tape application temperature range is 21°C to 38°C (70°F to 100°F). Initial tape application to surfaces at temperatures below 10°C (50°F) is not recommended because the adhesive becomes too firm to adhere readily. However, once properly applied, low temperature holding is generally satisfactory.

Storage and Shelf Life

The shelf life of 3M™ Thermally Conductive Interface Tapes TM-671SA and TM-672SA is 12 months from the date of manufacture when stored in original cartons at 21°C (70°F) and 50% relative humidity.

Regulatory

For regulatory information about this product, contact your 3M representative.

Important Note

Please consult Federal, State, and Local Regulations. State Volatile Organic Compound (VOC) regulations may prohibit the use of certain alcohol solutions or solvents. You should check with your state environmental authorities to determine whether use of a solution or solvent is restricted or prohibited.

Technical Information

The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.

Product Use

Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty, Limited Remedy, and Disclaimer

Unless an additional warranty is specifically stated on the applicable 3M product packaging or product literature, 3M warrants that each 3M product meets the applicable 3M product specification at the time 3M ships the product. 3M MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If the 3M product does not conform to this warranty, then the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

Limitation of Liability

Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.



Electronics Materials Solutions Division

3M Center, Building 225-3S-06
St. Paul, MN 55144-1000
1-800-251-8634 phone
651-778-4244 fax
www.3M.com/electronics

3M is a trademark of 3M Company.
Please recycle.
©3M 2014. All rights reserved.
60-5002-0390-0

