



# Surface Guard<sup>®</sup> PolyMask Protective Film

## 3W26X

Technical Data

February, 2017

**Product Description** Surface Guard<sup>®</sup> PolyMask 3W26X is a medium adhesion, UV resistant, co-extruded black/white temporary protection film, designed for a variety of surface protection applications.

Product Construction	Backing	Adhesive	Color	Standard Roll Sizes
	Polyethylene	Acrylic-Based	White (outside layer) Black ( inside layer)	Custom

**Typical Physical Properties** **Note: The following technical information and data should be considered representative or typical only, and should not be used for specification purposes.**

	Nominal Results	ASTM Test Method
Adhesion to Steel:	6 oz./in. width (1.65 N/25 mm)	D-3330**
Tensile:	2500 PSI	D-882**
Elongation:	450%	D-882**
Total Tape Thickness:	3 mils (0.08 mm)	D-3652**

\*\* ASTM test references modified per internal test methods.

- Features**
- Excellent UV resistance for up to 9 months.
  - Surface protection against dust, dirt and moderate abrasion encountered in handling, shipping and storage.
  - Stable adhesion levels resulting in good removability.
  - Film backing designed for good stamping and die-cutting.

- Application Ideas**
- General – smooth semi-gloss cultured marble, high pressure laminates.
  - Metals – 2B #3 and #4 finish stainless steel.
  - Painted – smooth satin-gloss.
  - Painted – lightly textured semi/high-gloss
  - Plastics – smooth satin-gloss.
  - Plastics - lightly textured semi/high-gloss.



# Surface Guard<sup>®</sup> PolyMask Protective Film

## 3W26X

---

<b>Application / Removal Techniques</b>	<ul style="list-style-type: none"><li>• For optimum performance, SG PolyMask Protective Films should be applied and removed at a temperature not less than 60°F (16°C).</li><li>• Surfaces should be dry and free from dirt, oil and other contaminants when film is applied.</li><li>• Protective film should be removed gradually beginning from one edge with a smooth even motion.</li></ul>
<b>Storage</b>	Store under normal conditions of 60° to 80°F (16° to 27°C) and 40 to 60% R.H in the original carton.
<b>Shelf Life</b>	To obtain best performance, use this product within 12 months from date of manufacture.
<b>For Additional Information</b>	To request additional product information or to arrange for sales assistance, call toll free 1-844-232-6783. Address correspondence to: SG PolyMask, 500 Thornburg Dr., Conover, NC 28613.
<b>Technical Information</b>	The technical information, recommendations and other statements contained in this document are based upon tests or experience that SG PolyMask believes are reliable, but the accuracy or completeness of such information is not guaranteed.
<b>Product Use</b>	Many factors beyond SG PolyMask's control and uniquely within user's knowledge and control can affect the use and performance of a SG PolyMask product in a particular application. Given the variety of factors that can affect the use and performance of a SG PolyMask product, user is solely responsible for evaluating the SG PolyMask product and determining whether it is fit for a particular purpose and suitable for user's method of application.
<b>Warranty and Limited Remedy</b>	Unless an additional warranty is specifically stated on the applicable SG PolyMask product packaging or product literature, SG PolyMask warrants that each SG PolyMask product meets the applicable SG PolyMask product specification at the time SG PolyMask ships the product. SG PolyMask MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If the SG PolyMask product does not conform to this warranty, then the sole and exclusive remedy is, at SG PolyMask's option, replacement of the SG PolyMask product or refund of the purchase price.
<b>Limitation of Liability</b>	Except where prohibited by law, SG PolyMask will not be liable for any loss or damage arising from the SG PolyMask product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.

---

ISO 9001

SG PolyMask – By Pregis  
500 Thornburg Drive SE  
Conover, NC 28613  
828-465-3053 (Office)  
828-465-2404 (Fax)  
[www.sgpolymask.com](http://www.sgpolymask.com)

This product was manufactured under a quality system registered to ISO 9001 standards by SG PolyMask